

Carpet Spotting & Upholstery Cleaning Procedures

Carpet Cleaning Instructions:

Utilize standard carpet spotting practices with **Split!** Carpet and Upholstery Cleaner.

Attend to the spill as quickly as possible, blotting the spill into a clean microfiber cloth when possible.

To remove stains, dilute at 12oz per gallon in a spray bottle.

Spray lightly; rub lightly with a soft brush or microfiber towel in the direction of the center of the stain.

Blot with a clean terry or microfiber cloth, turning frequently.

For upholstery, spray lightly and evenly, lightly scrub, then absorb with clean microfiber towels or:

Fill your extractor with only with cold water.

Use spray bottle with diluted **Split!** at 12 oz. per gallon to pre-spray

Do not extend dwell time. Rub area with a microfiber cloth or a soft brush.

Immediately use the extractors hose and upholstery tool for extracting with cold water.

Repeat if necessary. Avoid over wetting the upholstery.

Note - Extractors with a hose and upholstery tool can be used for effective spotting as a cold water extractor only. Use **Split!** for pre-spraying only.

Note: When first transitioning from detergent-based cleaning to non-detergent cleaning, you may experience "suds" in the carpet being cleaned. This is residue from previous detergent cleanings. If large volumes are present, you may consider wet extraction after scrubbing instead of dry extraction with bonnets. You will then proceed to low-moisture cleaning after that.